

How to set Date/Time

Please note: This leaflet only applies to software version 14 or above.



Step 1

Press and Hold "Mute" button for 2 seconds.



Step 2

Short Press "Mute" button once to select Clock Sync, Short Press again to enter time settings. Using the scroll button rotate up/down to select hour.

Repeat above to confirm minutes then Short Press "Mute" button to move onto Day/Date/Year settings



Step 3

To adjust the Day/Date/Year short press "Mute" button. Repeat Step 2 above until Day/Month/Year is correct.



Step 4

Press and Hold "Source" button for 2 seconds to exit menu and return to display.